



\* UNLESS SPECIFIED, ALL THE EXTENSION LINES IN EACH PAGE ARE CONNECTED TO PAGE 1.  
 THE SPECIFIED PAGE NO. IS IN THE BRACKET '1'.  
 \* THE SYMBOL Y IS TO +5V

- 20
- 21
- 22
- 23
- 24
- 25
- 26
- 27
- 28
- 29
- 30
- 31
- 32
- 33
- 34
- 35

- MOTOR 0
- MOTOR 1
- DC TC
- CAP LOCK
- MOTOR ON SK9 PW16
- MOTOR ON
- INIT SK7 PW21
- JK2
- JK1
- SK9
- TIMER
- AUDIO
- AS232
- CENTRONICS
- DC 1
- RTC
- ROM SEL

**Bondwell**

**BONDWELL INTERNATIONAL LTD**

---

**TITLE:** CPU & IO DECODE

<b>PREPARED BY:</b>	<b>DWG NO.:</b> A1	<b>REV.:</b>
<b>CHECKED BY:</b>		
<b>APPROVED BY:</b>		